

|        |   |   |   |     |     |     |   |   |   |     |     |     |   |   |   |     |    |    |     |     |    |     |    |     |     |    |
|--------|---|---|---|-----|-----|-----|---|---|---|-----|-----|-----|---|---|---|-----|----|----|-----|-----|----|-----|----|-----|-----|----|
| 家庭糸    |   | ▲ | ▲ |     |     | ▲   | ▲ | ▲ |   |     |     | ▲   |   |   |   | ▲   |    |    |     |     |    |     |    |     |     | ▲  |
| ボタン付   |   | ● | ● |     |     | ●   | ● | ● |   |     |     | ●   |   |   | ● |     |    | ●  |     |     |    |     |    |     |     | ●  |
| スパンロック |   | ◎ | ◎ |     |     | ◎   | ◎ | ◎ | ○ |     | ◎   |     |   | ◎ | ○ | ○   |    |    | ○   |     | ◎  |     |    |     |     | ◎  |
| カラーNo. | 1 | 2 | 3 | 301 | 302 | 303 | 4 | 5 | 6 | 304 | 309 | 305 | 7 | 8 | 9 | 310 | 10 | 11 | 306 | 307 | 12 | 311 | 13 | 308 | 315 | 20 |

|        |    |    |     |     |     |    |    |     |     |     |    |    |    |     |    |    |    |    |     |     |     |    |    |     |    |    |
|--------|----|----|-----|-----|-----|----|----|-----|-----|-----|----|----|----|-----|----|----|----|----|-----|-----|-----|----|----|-----|----|----|
| 家庭糸    |    |    |     |     | ▲   | ▲  |    |     |     |     | ▲  | ▲  |    | ▲   |    |    |    | ▲  |     |     |     | ▲  |    |     |    |    |
| ボタン付   | ●  |    |     |     |     | ●  |    |     |     | ●   | ●  |    |    |     | ●  |    |    | ●  | ●   |     | ●   | ●  |    |     |    |    |
| スパンロック |    | ◎  |     |     | ◎   | ◎  | ○  | ○   | ○   |     | ◎  | ◎  |    |     | ○  | ◎  | ◎  | ◎  | ◎   | ◎   | ◎   | ◎  | ◎  |     |    |    |
| カラーNo. | 21 | 22 | 316 | 320 | 317 | 23 | 24 | 321 | 318 | 319 | 25 | 26 | 27 | 322 | 30 | 31 | 32 | 33 | 401 | 402 | 403 | 34 | 35 | 404 | 36 | 37 |

|        |     |     |    |     |     |     |    |    |     |     |     |    |    |     |     |    |    |     |    |    |    |     |    |     |    |     |
|--------|-----|-----|----|-----|-----|-----|----|----|-----|-----|-----|----|----|-----|-----|----|----|-----|----|----|----|-----|----|-----|----|-----|
| 家庭糸    |     |     | ▲  |     |     |     | ▲  | ▲  |     |     |     | ▲  | ●  |     |     | ▲  |    | ▲   | ▲  | ▲  |    |     |    | ▲   |    |     |
| ボタン付   |     |     | ●  |     |     |     | ●  | ●  |     |     |     | ●  | ●  |     |     |    | ●  | ●   | ●  |    | ●  |     | ●  |     |    |     |
| スパンロック | ◎   |     | ◎  | ○   |     |     | ◎  | ◎  |     |     | ○   | ◎  | ◎  |     | ◎   |    | ◎  |     | ◎  | ◎  | ◎  |     |    | ◎   |    |     |
| カラーNo. | 410 | 418 | 38 | 411 | 412 | 413 | 39 | 40 | 414 | 415 | 419 | 41 | 42 | 420 | 416 | 43 | 44 | 417 | 45 | 50 | 51 | 421 | 52 | 422 | 53 | 423 |

|        |     |     |     |    |     |    |    |    |     |     |    |     |     |     |    |    |     |    |     |    |    |    |    |     |    |     |
|--------|-----|-----|-----|----|-----|----|----|----|-----|-----|----|-----|-----|-----|----|----|-----|----|-----|----|----|----|----|-----|----|-----|
| 家庭糸    |     |     |     | ▲  |     | ▲  | ▲  |    |     |     |    |     |     | ▲   |    |    | ▲   |    | ▲   | ▲  |    |    |    |     | ▲  |     |
| ボタン付   |     |     |     | ●  |     | ●  | ●  |    |     |     | ●  |     |     | ●   |    |    | ●   |    | ●   | ●  | ●  |    |    |     | ●  |     |
| スパンロック |     |     |     | ◎  |     | ◎  | ◎  |    |     | ◎   |    |     | ◎   | ◎   | ○  |    | ◎   |    | ◎   | ◎  | ◎  |    | ◎  | ◎   | ◎  | ◎   |
| カラーNo. | 425 | 426 | 427 | 54 | 428 | 57 | 55 | 56 | 430 | 431 | 60 | 432 | 436 | 433 | 61 | 62 | 434 | 63 | 435 | 64 | 65 | 66 | 70 | 510 | 71 | 501 |







